Savi® W740


Multi-Device Wireless Headset System

Guía de inicio rápido Guide de démarrage rapide Guia de Início Rápido

QUICK START GUIDE



plantronics



1 Volume/mute/flash button

Increase volume Short press up* Decrease volume Short press down*

Mute Short press in

Flash While on call, long press (1.5 seconds) up or down, will put call on hold and answer another.

2 Call control button

Answer/end call Short press

NOTE * If headset is worn on left, do opposite.

CAUTION For your safety, do not use headset at high volumes for extended periods of time. Doing so can cause hearing loss. Always listen at moderate levels. For more information on headsets and hearing visit plantronics.com/healthandsafety.


Please refer to the separate safety instructions for important product safety information prior to installation or use of the product.

Savi W740 has a WO2 base and a WH500 headset.

86111-01 (04.11)

Headset Customize and Charge

Connect battery.



2 Choose headset wearing style and use fit kit to assemble.



Over-the-ear OR Over-the-head OR Behind-the-head


3 Attach charge cradle to base.



4 Plug one end of power supply into power jack on back of the base and other end into working power outlet.



5 To charge, dock headset in base, minimum of 20 minutes.



NOTE This product has a replaceable battery. Use only the battery type supplied by Plantronics.


Desk Phone Connect and Call

- 1 Choose desk phone setup A, B, or C and connect cables.
 - A Desk phone (standard)



B Desk phone + HL10 lifter (sold separately)

See user quide at plantronics.com/accessories



C Desk phone + EHS cable (sold separately)

See user quide at plantronics.com/accessories




2 While wearing headset, short press base desk phone button.




NOTE If you don't have remote call control through a lifter (HL10) or cable (EHS), manually remove desk phone handset before each call.

3 If you do not hear a dial tone, open side panel and adjust middle configuration switch (A–G) until you do. Default setting $\boldsymbol{\mathsf{A}}$ works for majority of desk phones.



- 4 Dial test call from desk phone.
- **5** End call by pressing headset call control button.



Mobile Connect and Call

1 Press down and hold Bluetooth pairing button (4 seconds) on Savi base until indicator LED flashes red and blue.



2 Place Bluetooth mobile phone into search mode. Select SAVI 7xx from the list of found devices.




3 If prompted by mobile phone, type 0000 as passcode. Bluetooth indicator LED on base will turn solid blue when base has an active connection with mobile phone.



4 While wearing headset, short press base mobile button.




- 5 Dial test call from mobile phone.
- **6** End call by pressing headset call control button.



Computer Connect and Call


Connect USB cable.



- 2 Load Plantronics software by visiting plantronics.com/software and click on download button
- **3** While wearing headset, short press base computer button.



- 4 Dial test call from computer softphone.
- **5** End call by pressing headset call control button.



NEED MORE HELP?

Technical support plantronics.com/support

Online user quide http://docs.plantronics.com/savi-700