

# Quick User Guide

plantronics®

## Plantronics Savi W745

Multi-Device Wireless Headset System




Three convertible wearing styles

Press top buttons to switch between devices.  
Green LED denotes active device.



### Bluetooth pairing

Hold 4 seconds until LED flashes red and blue. Select "Savi 7xx" from Bluetooth device. If prompted, passcode is 0000. LED on base will turn solid blue once active connection is made.



### 1 Volume/Mute/Flash Button

Press up or down to adjust volume  
Press in to mute/unmute  
During a call, press up or down for 1.5 sec to switch between calls

### 2 Call Control Button

Press to answer/end calls

### 3 Headset LED

Flashes white when in use

**NEED SUPPORT?**

800.641.6416 *or*  
CHAT ONLINE

 **unified**  
communications™  
.com